User Manual

ELECTRA-T24

24 Gigabit Managed PoE Switch



Installation manual introduction

The Product installation manual mainly describes ELECTRA-T24 PoE switch hardware features, installation methods, and precautions during the installation

This manual includes the following chapters:

Chapter 1: Product Introduction. Briefly describes the basic features of the switch and the appearance details.

Chapter 2: Product Installation. Guide the switch hardware installation methods and precautions.

Chapter 3: Hardware Connections. Guide the connection between switches and other devices and precautions.

Chapter 4: Technical Specifications.



NOTE: To avoid potential device damage and personal injury, read the related information in this manual before installing the device.

Agreement

The term "switch" mentioned in this manual, unless otherwise specified, refers to

24-port full Gigabit managed PoE switch, hereinafter referred to as ELECTRA-T24

Some pictures for the schematic, the product itself and pictures may be different



This icon indicates the items to be cautioned in the operation. If the operation is wrong, the equipment may be damaged and other adverse consequences.

1.1Product introduction

ELECTRA-T24 is managed PoE switch for security transmission and WIFI coverage, meet the WIFI AP, IP-camera, WIFI bridge, IP phones and other types of equipment PoE power supply needs. Products using a new generation of high-performance hardware and software platforms, providing flexible, cost-effective full Gigabit access and uplink ports, support for Layer 3 routing protocols, complete security mechanisms, improved ACL / QoS strategy and rich VLAN capabilities, it is easy to manage and maintain , meet the users' requirements for network equipment easy to manage, high security and low cost. It is suitable for network access, aggregation and core applications in campus, hotel and enterprise campus.

PoE (Power over Ethernet) refers to the power over Ethernet technology. It refers to the transmission of data signals to some IP-based terminals (such as IP phones, wireless access point APs, network cameras, etc.) and also provide DC power supply technology. These devices that accept DC power supply are called powered devices (PDs)

1.2 Packing list


Open the package carefully check the following list

| Commodity | Quantity | Description |
|-------------|----------|-------------------------------|
| PoE switch | 1pcs | No |
| Power cord | 1pcs | Optional |
| Bracket | 2pcs | Fixed on rack mount |
| User manual | 1pcs | Guide users to install switch |

1.3 Appearance

Front Panel

Including indicators, RJ45 port, shortcut buttons, RST button, SFP port, CONSOLE port, as shown in Figure 1.1 below



Indicators

| ELECTRA-T24 | The indicator working | status is shown as the following table | |
|-------------|-----------------------|--|--|
|-------------|-----------------------|--|--|

| Indicators | Title | Color | Work status | Description |
|------------|---------------------------|-------|----------------|--|
| | | | Solid | Power is normal |
| POWER | Power indicator | Red | Off | No power, the power switch is not turned on, power supply is abnormal |
| POE | POE power indicator | Red | Solid | The corresponding RJ45 port is connected to the powered device and the power supply is normal |
| POE | | Red | Off | The corresponding RJ45 port is not connected to the powered device or the power supply is abnormal |
| LINK/ACT | Connection | Green | Blinking | A valid link is established |
| LINNACT | indicator | | Off | An invalid link is established |
| | System | Green | Blinking | System is functioning properly |
| | indicator | | Off | System is functioning improperly Software is damaged |
| G1-4 | SFP | Green | Blinking | A valid link is established on the SFP port |
| 61-4 | indicator | | Off | An invalid link is established on the SFP port |

Shortcut button

• **QOS**: Improve video data processing capabilities and improve the monitoring of Caton and Mosaic phenomena in the network

• CCTV: 1-8 port rate down to 10Mbps, but the transmission distance up to 250 meters

• VLAN: Isolating ports 1-24 from each other, suppress network storms effectively and improve network performance

Al power supply: Detect PD, power failure and restart dead equipment

RJ45 Port

ELECTRA-T24 with24 10/100/1000Mbps PoE port, all ports support IEEE802.3af and IEEE802.3at standard

When the switch mode of operation is CCTV mode, 1-8 port can support 250 meters power supply with 10Mbps speed rate

♦ SFP Port

ELECTRA-T24 provide four Gigabit SFP optical ports (G1~G4), can be inserted into the Gigabit SFP module

RST Button

When the switch is powered on, press the button with the needle to release the device and enter the restarting state. When the SYS lamp restarts, the device restarts. When the switch is powered on, press and hold the button for more than 5s to release the button and enter the reset state. When SYS is re-lit, the device is reset successfully Console port used to connect to computer or other terminal to manage or configure the switch.

Back Panel

Including: power socket, power switch, ground terminal



I

Power socket

A 100-240VAC 50/60 Hz power receptacle for accommodating the supplied power cord

Power switch

Turn on/off the power switch, control the power switch

Ground terminal

Please use the grounding wire to prevent lightning. To avoid product lightning strikes and extend product life

Chapter 2 Installation

2.1 Installation Precautions



Note: To avoid improper use of equipment damage and personal injury, please observe the following precautions

Installation safety precautions

- The power should be kept off during the installation, while wearing antistatic wrist, and to ensure well touch between anti-static wrist and skin to avoid potential safety hazard;
- The switch just work normally when it is powered by the correct power supply. Make sure that the power supply voltage matches the voltage indicated by the switch
- Before powering on the switch, make sure that the power circuit is not overloaded, which may affect the normal operation of the switch and even cause unnecessary damage
- To avoid the risk of electric shock, do not open the case while the switch is working. Do not open the case even when it is not powered
- Before cleaning the switch, unplug the switch from the power cord and do
 not wipe it with wet cloth. Do not wash it with liquid

Temperature and humidity

To ensure the long-term stability working of the switch , please maintain a certain temperature and humidity environment. High or low humidity easily lead to leakage of insulation materials, deformation and even the corrosion of metal parts, the temperature is too high will accelerate the aging process of insulating materials, seriously affecting the service life of equipment. The normal operation of this series of switches and storage temperature / humidity are as follows

| Environmental description | temperature | Relative humidity |
|---------------------------|-------------|---------------------------------|
| Working environment | 0°C~40°C | 10% ~ 90% RH no condensation |
| Storage environment | -40℃ ~ 70℃ | 5% ~ 90% RH no condensation |

♦ Altitude



Products with this logo are only for safe use in areas below 2000m altitude

Dust-proof

Dust on the switch surface will cause electrostatic adsorption, poor contact of the metal contacts. Although the device itself has done some measures in anti-static, but when the static electricity exceeds a certain intensity, it will still cause fatal damage to the electronic components on the internal circuit board. In order to prevent static electricity from affecting the normal operation of the equipment, please note the following:

Regular dust, keep the indoor air clean;

Make sure the equipment is well grounded to ensure smooth transfer of static electricity

Electromagnetic interference

Electromagnetic interference have an impact on the device capacitance, inductance and other electronic components by capacitive, inductive coupling, impedance coupling and other conductive, in order to reduce the adverse

effects caused by electromagnetic interference, please note the following:

Power supply system to take the necessary anti-grid interference measures; Switches should be far away from high-frequency high-power, high-current devices, such as wireless transmitters;

If necessary, take electromagnetic shielding measures

♦ Lightning protection

When a lightning strike occurs, a strong current will be generated in an instant cause fatal damage to electronic equipment. To achieve better lightning

protection, please note the following:

Make sure the rack and the ground to maintain good contact; Make sure the power outlet is in good contact with the earth; Reasonable wiring, to avoid the internal sense ray;

Outdoor wiring, it is recommended to use the signal lightning protection device

♦ Installation desk requirement

Regardless of whether the switch is installed in a rack or on another horizontal workbench, be aware of the following:

Make sure the rack or workbench is stable, strong, and can withstand at least 5.5Kg weight;

Make sure the rack has a good cooling system, or maintain good indoor ventilation;

Make sure the rack is well grounded, the power outlet and switch are within 1.5 meters

Prepare tools for installation

You may need to use a screwdriver during installation, electrostatic wrist strap, fiber optic cable and other tools to prepare your own

2.2 Product installation

19-inch standard rack installation

ELECTRA-T24 is designed according to the standard 19-inch rack size, you can easily install to the rack, the specific installation steps are as follows:

First, Check rack grounding and stability;

Second, Install the two L-brackets in the accessory on each side of the switch panel and secure with the screws provided in the accessory

Third, place the switch in an appropriate place in the rack and be supported by the bracket. Screw the L-shaped bracket to the guide groove fixed on both ends of the rack to ensure that the switch is stable and horizontally installed on the rack



Note:


Good grounding rack is anti-static equipment, anti-leakage, lightning protection, anti-jamming important guarantee, so to ensure that the rack ground wire properly installed;

Installation equipment within the rack from the bottom up, to avoid overload installation;

Avoid placing other heavy objects on switch to avoid accidents; Ensure heat dissipation and air circulation.

3.1RJ45 port connection-

Connect the RJ45 port of the switch and the corresponding network device via cables, the POE power supply function of the switch is default enabled on the downlink port of the switch, which can be used for IEEE802.3af or IEEE802.3at standards powered devices such as APs, bridges, and network cameras





Note:

When the switch connected workstations, servers, routers or other ethernet devices the cable length should be within 100 meters; The Auto-MDI / MDIX ethernet interface is enabled by default. Category 5,the standard network cable or crossover cable can be used for Ethernet connection. Do not connect the RJ45 port to the phone line

3.2 SFP Port connection

ELECTRA-T24 SFP port only support Gigabit fiber module. Recommended use of standard SFP module products

The process of installing a fiber module on a switch is as follows:

First, grasp the optic fiber module from the side, insert it smoothly along the SFP port slot until the optic fiber module and switch are in close contact;

Second, confirm the Rx and Tx ports of the fiber module when connecting, insert one end of the fiber into the Rx and Tx ports correspondingly, ensure that the Tx and Rx ends of the interface are connected correctly and the other end of the fiber is connected to another device;

Third, please check the corresponding indicator light status after power on. If the light blinking that the link is properly connected, if the light is off, the link is failure, please check the line to confirm that the corresponding equipment is enabled.

Note:

Does not allow excessive bending fiber, the radius of curvature should not be less than 10cm;

Ensure the cleanliness of the fiber surface;

Please do not look directly into the optical fiber connector with your eyes as this may cause eye injury

3.3 Check before power on-

Check whether the outlet power supply meets the switch specifications;

Check the power, switches, racks and other equipment have been properly grounded;

Check whether the switch and other network devices are connected properly

3.4 Device initialization

The switch automatically initializes when the power switch is turned on. Indicator will appear the following situation:


After the power is turned on, the power indicator remains on, the other indicator is off at this time;

After about 1 second, all lights except for the power light turn on for about 35 seconds and then turn off; when the SYS light goes flashing, the system runs normally

Port LEDs indicates the connection status of each port, indicating that the switch has started to work normally

3.5 Web Login-

Step1. In the normal operation of the device, connect the computer to the switch's RJ45 port by network cables



Step 2. Manually changed the computer IP address to 192.248.254.X (X is 2 \sim 254), subnet mask is 255.255.255.0

Step3 Open computer's browser, type 192.248.254.1 in the address box, hit the Enter key

Step4. Enter the default username and password "admin" and then click Login

Step5. Entered the switch web management interface successfully when you see picture as below, you can begin to configure the switch

| | Hored ® | | | Chinese Reslart |
|----|---------------|------------------|---|------------------------------------|
| 9 | | System Info | | System load |
| 0 | Port Config | Product ID | DF5700_24GP_4TF | CPU Utilization Memory Utilization |
| | | Serial Number | \$N0000026 | 50 10 |
| 39 | | MAC Address | 00000020000 | 27 OU 3 7 MM 3 |
| 17 | | Firmware Version | V3.6.5.6-g28544b6 | |
| = | Layer3 Config | Compile Time | Feb 7 2018 09:33:28 | . 15 |
| _ | | Uptime | 0 Day 1 Hours 24 Minutes | |
| 10 | | System Time | 1970-01-01 09:24644 synchronis time system | |
| • | | Ports Status | | |
| | | | | |
| | | CPU Usage | | Memory Usage |
| | | | Nire Uter Spite Sig Sig Sig Sig | € staf |

4.1Hardware Specifications

| Network standard | IEEE 802.3: Ethernet Media Access Control (MAC) protocol IEEE 802.3i:10BASE-T Ethernet IEEE 802.3u:100BASE-TX fast Ethernet IEEE 802.3ab:1000BASE-T gigabit Ethernet IEEE 802.3ab:1000BASE-X gigabit Ethernet (fiber) IEEE 802.3ac:100BASE-X gigabit Ethernet (fiber) IEEE 802.3ac:10GBASE-SR/LR 10G Ethernet (fiber) IEEE 802.3ac: comply link aggregation standard IEEE 802.3ac: flow control IEEE 802.3x: flow control IEEE 802.1p: About the traffic priority of the second layer of Qos / Cos protocol (multicast filtering) IEEE 802.1q:VLAN Bridge operation IEEE 802.1s:MSTP spanning tree IEEE 802.1s:MSTP spanning tree IEEE 802.1w:RSTP spanning tree IEEE 802.3af IEEE 802.3at | | |
|----------------------|--|--|--|
| | 24 10/100/1000Mbps RJ45 port | | |
| Port | 4 gigabit SFP fiber port | | |
| | 1 Console port | | |
| | 24 10/100/1000Mbps RJ45 port support PoE | | |
| PoE | Max 400W | | |
| | Single port max 30W | | |
| | 28 Link/Act LEDs | | |
| LEDs | 24 POE LEDs | | |
| | 1 Power LEDs | | |
| | Forwarding mode: store and forward | | |
| | Switch Volume (Full-duplex) : 56Gbps | | |
| Performance | Packet forwarding rate: 41.664Mpps | | |
| | 8K MAC address table | | |
| Input | 100-240V/50-60Hz | | |
| Dimension (L×W×H) | 440mm×320mm×44mm | | |

4.2 Software Specifications

| | One key VLAN |
|----------------------|---|
| Shortcut function | One key CCTV(1-8 port 250meters PoE distance) |
| | One key Q0S (Video priority) |
| | One key AI power supply |
| Routing | Support RIP V1/V2 dynamic routing |
| Ŭ | Support static routing |
| | Support DHCP server |
| DHCP | Support DHCP reply |
| | Support DHCP Snooping |
| VLAN | Support 4K VLAN |
| VLAN | Support 802.1Q VLAN、Port VLAN、Voice VLAN |
| | Support setting the PoE port priority |
| PoE | Support setting PoE power supply period |
| | Support setting port power |
| | Comply the IEEE 802.1d standard |
| MAC address table | Support MAC address learning and aging automatically |
| | Support static, dynamic, filter address table |
| | Based on user rating management and password protection |
| | Support based on the port number, IP address, MAC address restrictions on user access |
| Safety | Icmp-echo、DoS protection |
| | Support DHCP Snooping、DHCP attack protection |
| | Support port security, port isolation |
| Access control (ACL) | Support L2(Layer 2) ~ L4(Layer 4) packet filtering function |
| | Support port mirroring, port redirection, flow rate limit, QoS re-marking |
| | Support IGMP v1/v2 Snooping |
| | |
| Multicast | Support static multicast |

| | Support 8 port queue | |
|----------------|--|--|
| QoS | Support port priority, 802.1p priority, DSCP priority | |
| | Support SP、RR、WRR、WFQ Priority scheduling algorithm | |
| Spanning Tree | Support STP(IEEE 802.1d), RSTP(IEEE 802.1w) and MSTP(IEEE 802.1s) protocol | |
| | Support loop protection, BPDU protection | |
| | Support WEB management(HTTP) | |
| | Support CLI (Telnet、local serial port) | |
| | Support SNMP V1/V2/V3, Compatible with public MIBS | |
| Management and | Support LLDP、RMON | |
| maintenance | Support IP Source protection、DoS protection | |
| | Support CPU monitor、memory monitoring | |
| | Support system log | |
| | Support cable testing | |
| | Support IGMP v1/v2 Snooping | |
| Multicast | Support static multicast | |
| | Support Multicast VLAN | |

4.2 Features

> 1-8 port support 250Meters long-distance power supply (recommended cat5e or 6 network cable)

Support a key VLAN, the port 1-24 isolated from each other, which can effectively inhibit network storms, improve network performance

Supports IEEE 802.3af / at standard, automatically detects and identifies devices that comply with the IEEE 802.3af / at standard and supply power to it

Support Auto MDI/MDIX;

Adopt store-and-forward exchange method

intelligent power supply, the lowest power consumption, ensure PD power needs

> With power circuit protection, protect the safety of PD

 No configuration characteristics of the power supply is automatically supplied to the adaptive equipment;

> Fanless design, energy saving and environmental protection; no noise, reduce the impact on the environment

- Small, exquisite design
- Support port without link power saving function
- All ports have wire-speed forwarding capability
- Plug and play ,easy to use